Geant 4

IEEE Nuclear Science Symposium and Medical Imaging Conference Short Course

Simulation Techniques Using Geant4

Maria Grazia Pia (*INFN Genova, Italy*)
MariaGrazia.Pia@ge.infn.it

Dresden, 18 October 2008

http://www.ge.infn.it/geant4/events/nss2008/geant4course.html

This course exploits training material developed by several Geant4
Collaboration members: thanks to all of them!



Particles and Processes

Basic concepts underlying Geant4 physics



Physics

From the Minutes of LCB (LHCC Computing Board) meeting on 21/10/1997:

"It was noted that experiments have requirements for independent, alternative physics models. In Geant4 these models, differently from the concept of packages, allow the user to understand how the results are produced, and hence improve the physics validation. Geant4 is developed with a modular architecture and is the ideal framework where existing components are integrated and new models continue to be developed."

Physics: general features

- Ample variety of physics functionality
- Uniform treatment of electromagnetic and hadronic processes
- Abstract interface to physics processes
 - Tracking independent from physics
- Distinction between processes and models
 - often multiple models for the same physics process (complementary/alternative)
- Open system
 - Users can easily create and use their own models



Physics: general features

Transparency

- supported by encapsulation and polymorphism)
- Calculation of cross-sections independent from the way they are accessed (data files, analytical formulae etc.)
- Distinction between the calculation of cross sections and their use
- Calculation of the final state independent from tracking
- Etc.
- Modular design, at a fine granularity, to expose the physics
- Explicit use of units throughout the code
- Public distribution of the code, from one reference repository worldwide



Data libraries


 Systematic collection and evaluation of experimental data from many sources worldwide

Databases

- ENDF/B, JENDL, FENDL, CENDL, ENSDF, JEF, BROND, EFF, MENDL, IRDF, SAID, EPDL, EEDL, EADL, SANDIA, ICRU etc.
- Collaborating distribution centres
 - NEA, LLNL, BNL, KEK, IAEA, IHEP, TRIUMF, FNAL, Helsinki, Durham, Japan etc.
- The use of evaluated data is important for the validation of physics results of the experiments

Processes

- Processes describe how particles interact with material or with a volume
- Three basic types
 - At rest process(eg. decay at rest)
 - Continuous process(eg. ionisation)
 - Discrete process(eg. Compton scattering)



- Transportation is a process
 - interacting with volume boundary
- A process which requires the shortest interaction length limits the step

Outline

What is tracked

G4ParticleDefinition G4DynamicParticle G4Track

The process interface

G4VProcess
How processes interact with tracking

The production cuts

Why production cuts are needed

Using Geant4 physics


G4VUserPhysicsList Concrete physics lists

G4ParticleDefinition

- Intrinsic particle properties
 - mass, width, spin, lifetime...
- Sensitivity to physics
- This is realized by a G4ProcessManager attached to the G4ParticleDefinition

- G4ProcessManager manages the list of processes the user wants the particle to be sensitive to
- G4ParticleDefinition does not know by itself its sensitivity to physics

Particles and Process design



More about particle design

G4DynamicParticle


- Describes the purely dynamic part (i.e. no position, nor geometrical information...) of the particle state:
 - momentum, energy, polarization
- Holds a G4ParticleDefinition pointer
- Retains eventual pre-assigned decay information
 - decay products
 - lifetime

More about particle design

G4Track

- Defines the class of objects propagated by Geant4 tracking
- Represents a snapshot of the particle state
- Aggregates
 - a G4ParticleDefinition
 - a G4DynamicParticle
 - geometrical information:
 - position, current volume ...
 - track ID, parent ID;
 - process which created this G4Track
 - weight, used for event biasing





The classes involved in building the **PhysicsList** are:

- the **G4ParticleDefinition** concrete classes
- the **G4ProcessManager**
- the processes



G4VProcess

Abstract class defining the common interface of all processes in Geant4

AlongStep

PostStep

- Define three kinds of actions:
- AtRest actions: decay, annihilation ...
- AlongStep actions continuous interactions occurring along the path, like ionisation
- PostStep actions: point-like interactions, like decay in flight, hard radiation...
- A process can implement any combination of the three AtRest, AlongStep and PostStep actions:
 - eg: decay = AtRest + PostStep

G4VProcess actions

• Each action defines two methods:

AlongStep
PostStep

- GetPhysicalInteractionLength()
 - used to limit the step size
 - either because the process triggers an interaction or a decay
 - or in other cases, like fraction of energy loss, geometry boundary, user's limit...

Dolt()

- implements the actual action to be applied to the track
- implements the related production of secondaries

Processes, ProcessManager and Stepping

- G4ProcessManager retains three vectors of actions:
 - one for the AtRest methods of the particle
 - one for the AlongStep ones
 - one for the PostStep actions
 - these are the vectors which the user sets up in the PhysicsList and which are used by the tracking
- The stepping treats processes generically
 - it does not know which process it is handling
- The stepping lets the processes
 - cooperate for AlongStep actions
 - compete for PostStep and AtRest actions
- Processes emit also signals to require particular treatment:
 - notForced: normal case
 - forced: PostStepDoIt action applied anyway;
 - conditionallyForced: PostStepDoIt applied if AlongStep has limited the step
 Geant4 Course M. G. Pia



Invocation sequence of processes: particle in flight

- At the beginning of the step, determine the step length
 - consider all processes attached to the current G4Track
 - define the step length as the smallest of the lengths among
 - all AlongStepGetPhysicalInteractionLenght()
 - all PostStepGetPhysicalInteractionLength()
- Apply all AlongStepDolt() actions at once
 - changes computed from particle state at the beginning of the step
 - accumulated in G4Step
 - then applied to G4Track, by G4Step
- Apply PostStepDolt() action(s) sequentially, as long as the particle is alive
 - apply PostStepDoIt() of the process which proposed the smallest step length
 - apply forced and conditionnally forced actions

Invocation sequence of processes: particle at rest

- If the particle is at rest, is stable and cannot annihilate, it is killed by tracking
 - more properly said: if a particle at rest has no AtRest actions defined, it is killed
- Otherwise determine the lifetime
 - Take the smallest time among all AtRestGetPhysicalInteractionLenght()
 - Called *physical interaction length*, but it returns a time
- Apply the AtRestDolt() action of the process which returned the smallest time

Processes ordering


Ordering of following processes is critical:

 assuming n processes, the ordering of the AlongGetPhysicalInteractionLength of the last processes should be:

[n-2] ...[n-1] multiple scattering[n] transportation

Why?

- Processes return a true path length
- The multiple scattering virtually folds up this true path length into a shorter geometrical path length
- Based on this new length, the transportation can geometrically limit the step



Other processes ordering usually does not matter

Cuts in Geant4

- In Geant4 there are no tracking cuts
 - particles are tracked down to a zero range/kinetic energy
- Only production cuts exist
 - i.e. cuts allowing a particle to be born or not

Why are production cuts needed?

- Some electromagnetic processes involve infrared divergences
 - this leads to an infinity [huge number] of smaller and smaller energy photons/electrons (such as in Bremsstrahlung, δ -ray production)
 - production cuts limit this production to particles above the threshold
 - the remaining, divergent part is treated as a continuous effect (i.e. *AlongStep* action)



Range vs. energy production cuts


- The production of a secondary particle is relevant if it can generate visible effects in the detector
 - otherwise "local energy deposit"
- A range cut allows to easily define such visibility
 - "I want to produce particles able to travel at least 1 mm"
 - criterion which can be applied uniformly across the detector (whole or "region")
- The same energy cut leads to very different ranges
 - for the same particle type, depending on the material
 - for the same material, depending on particle type
- The user specifies a range cut in the PhysicsList
 - this range cut is converted into energy cuts
 - each particle (G4ParticleWithCut) converts the range cut into an energy cut, for each material
 - processes then compute the cross-sections based on the energy cut



Effect of production thresholds

Geant 4

500 MeV incident proton



Threshold in range: 1.5 mm




455 keV electron energy in liquid Ar


2 MeV electron energy in Pb

In GEANT 3

one must set the cut for delta-rays (DCUTE) either to the Liquid Argon value, thus producing many small unnecessary δ-rays in Pb,



or to the Pb value, thus killing the δ -rays production everywhere



Violations of the production threshold

- In some cases particles are produced even if they are below the production threshold
- This is intended to let the processes do the best they can
- It happens typically for
 - decays
 - positron production:
 - in order to simulate the resulting photons from the annihilation
 - hadronic processes:
 - since no infrared divergences affect the cross-sections
- Note these are not "hard-coded" exceptions, but a sophisticated, generic mechanism of the tracking



G4VUserPhysicsList

- It is one of the mandatory user classes (abstract class)
- Pure virtual methods
 - ConstructParticles()
 - ConstructProcesses()
 - SetCuts()

to be implemented by the user in his/her concrete derived class

Electromagnetic physics

energy loss


- electrons and positrons
- γ, X-ray and optical photons
- muons
- charged hadrons
- ions

Comparable to Geant3 already in the α release (1997)

Further extensions (facilitated by the OO technology)

- High energy extensions
 - needed for LHC experiments, cosmic ray experiments...
- Low energy extensions
 - fundamental for space and medical applications, dark matter and v experiments, antimatter spectroscopy etc.
- Alternative models for the same process

- Multiple scattering
- Bremsstrahlung
- Ionisation
- Annihilation
- Photoelectric effect
- Compton scattering
- Rayleigh effect
- γ conversion
- e⁺e⁻ pair production
- Synchrotron radiation
- Transition radiation
- Cherenkov
- Refraction
- Reflection
- Absorption
- Scintillation
- Fluorescence
- Auger



All obeying to the same abstract Process interface \rightarrow transparent to tracking

eant 4 Geant4 Course – M. G. Pia

Hadronic physics

- Completely different approach w.r.t. the past (Geant3)
 - native
 - transparent
 - no longer interface to external packages
 - clear separation between data and their use in algorithms
- Cross section data sets
 - transparent and interchangeable
- Final state calculation
 - models by particle, energy, material

Ample variety of models

- the most complete hadronic simulation kit on the market
- Alternative/complementary models
- it is possible to mix-and-match,
 with fine granularity
- data-driven, parameterised and theoretical models

Consequences for the users

- no more confined to the black box of one package
- the user has control on the physics used in the simulation, which contributes to the validation of experiment's results



Summary

- Transparency and modularity are the key characteristics of Geant4 physics
- Ample variety of processes and models
 - Openness to extension and evolution thanks to the OO technology
- The PhysicsList exposes, deliberately, the user to the choice of physics (particles + processes) relevant to his/her application
 - This is a critical task, but guided by the framework
 - Examples can be used as starting point
- Physics processes and models are documented in Geant4 Physics Reference Manual