Modellistica Medica

Maria Grazia Pia INFN Genova

Scuola di Specializzazione in Fisica Sanitaria Genova Anno Accademico 2002-2003

Maria Grazia Pia, INFN Genova



Highlights of other physics features

Maria Grazia Pia, INFN Genova

Hadronic physics

- Completely different approach w.r.t. the past (Geant3)
 - native
 - transparent
 - no longer interface to external packages
 - clear separation between data and their use in algorithms
- Cross section data sets
 - transparent and interchangeable
- Final state calculation
 - models by particle, energy, material

- Ample variety of models
 - the most complete hadronic simulation kit on the market
 - alternative and complementary models
 - it is possible to mix-and-match, with fine granularity
 - data-driven, parameterised and theoretical models
- Consequences for the users
 - no more confined to the black box of one package
 - the user has control on the physics used in the simulation, which contributes to the validation of experiment's results

Parameterised and data-driven hadronic models

4 Rapidity y

2

۵

Based on experimental data

- Some models originally from ٥ **GHFISHA**
 - completely reengineered into OO design
 - refined physics parameterisations
- New parameterisations ٥
 - pp, elastic differential cross section
 - nN, total cross section
 - pN, total cross section
 - np, elastic differential cross section
 - πN , total cross section
 - πN , coherent elastic scattering





p elastic scattering on Hydrogen



a di Specializzazione in Fisica Sanitaria, Univ. Genova

Parameterised and data-driven hadronic models



Maria Grazia Pia, INFN Genova



- Intermediate energy range, O(100 MeV) to O(5 GeV), intra-nuclear transport
- High energy range, *hadronic generator* régime

Maria Grazia Pia, INFN Genova

Radioactive Decay Module

- Handles α , β -, β +, ν and anti- ν , de-excitation γ -rays
 - can follow all the descendants of the decay chain
 - can apply variance reduction schemes to bias the decays to occur at userspecified times of observation
- Branching ratio and decay scheme data based on the Evaluated Nuclear Structure Data File (ENSDF)
- Geant4 photo-evaporation model is used to treat prompt nuclear deexcitation following decay to an excited level in the daughter nucleus
- Applications:
 - underground background
 - backgrounds in spaceborne γ -ray and X-ray instruments
 - radioactive decay induced by spallation interactions
 - brachytherapy
 - etc.

Maria Grazia Pia, INFN Genova

Fast simulation

Geant4 allows to perform full and fast simulation in the same environment

- The <u>parameterisation</u> process produces a direct detector response, from the knowledge of particle and volume properties
 - hits, digis, reconstructed-like objects (tracks, clusters etc.)
- Great flexibility
 - activate fast /full simulation <u>by detector</u>
 example: *full simulation for inner detectors, fast simulation for calorimeters*
 - activate fast /full simulation by geometry region
 example: fast simulation in central areas and full simulation near cracks
 - activate fast /full simulation <u>by particle type</u>
 example: in e.m. calorimeter, e/γparameterisation + full simulation of hadrons
 - <u>parallel geometries</u> in fast/full simulation example: inner and outer tracking detectors distinct in full simulation, but handled together in fast simulation

Maria Grazia Pia, INFN Genova

Event biasing

- Geant4 provides facilities for event biasing
- The effect consists in producing a small number of secondaries, which are artificially recognized as a huge number of particles by their statistical weights
- Event biasing can be used, for instance, for the transportation of slow neutrons or in the radioactive decay simulation
- Various variance reduction techniques available